



Biće Vam potrebno: Temperaturni senzor/senzori. Telldus Live! Pro.

Korišćenjem sistema događaja za nadgledanje Vaše je jeftino i sprečava incidente. Normalni temperaturni senzor se može koristiti da nadgleda frižider ili zamrzivač. Stavite senzor u vaš frižider i kreirajte događaj da ga nadgledate.

Dodajte temperaturni okidač i podesite nivo upozorenja na nešto veću temperaturu od normalne temperature.



Add sensor trigger X

Choose sensor:

Freezer ▼ Temperature ▼ -16.2

Choose threshold:

goes over ▼ -10

[Advanced settings »](#)

[Add »](#)



Dodajte jednu email akciju i jednu SMS akciju u događaj tako da budete obavešteni ako se nešto desi Vašem frižideru ili zamrzivaču. Dobijanje SMS-a ako vrata nisu dobro zatvorena može da Vam sačuva mnogo jer vaša hrana neće biti uništena...

The screenshot shows the 'Actions' screen where a condition is being set up. A blue dashed box encloses the '@' symbol icon, indicating it is selected. Below the toolbox, there are icons for sound, '@', and a pen.

Add email action

Email address:

Message:
Check the temperature in the
freezer!

Advanced settings »

Add »

Add sms action

Phone number: +46 712345678

Message:
Check the temperature in the
freezer!

Options: Normal message

SMS credits: Your credits: 16

50 credits (€5) 100 credits (€9)

Advanced settings »

Add »

Evo kako događaj treba da izgleda:

The screenshot shows the 'Freezer alarm' scenario setup. It includes three main sections: Triggers, Conditions, and Actions.

Triggers: Shows a blue dashed box around the '@' symbol icon, indicating it is selected. Below the toolbox, there are icons for sound, '@', and a pen.

Conditions: Shows a blue dashed box around the 'SMS' icon, indicating it is selected. Below the toolbox, there are icons for sound, '@', and a pen.

Actions: Shows a blue dashed box around the '@' and 'SMS' icons, indicating they are selected. Below the toolbox, there are icons for sound, '@', and a pen.

Napomena! Izolacione obloge u frižideru mogu da blokiraju radio signale. Pokušajte da koristite senzor sa provodnikom (žicom) a uređaj neka bude izvan frižidera.

